



Getting started...

Place the Wonder Walker™ on a flat surface in front of you, with the leash extending to the right, and the SOLID COLOR side (underside) of the material facing up.


Identify the head halter (the neck strap and the nose loop), the keeper, and the leash. **(figure 1)**

Depending on the size of your dog, you may wish to slide the keeper several inches TOWARD the end of the leash to allow greater ease in fitting the head halter. The larger your dog, the further you may need to move it.



Open the neck strap wide enough to easily slip over your dog's head, taking care that the cross-over seam section is on the UNDER side of your dog's jaw. **(figure 2)** If the neck loop will not open wide enough, slide the keeper further TOWARD the end of the leash to allow more

Position the neck strap high on the dog's neck, near the base of his skull, and adjust the material so that the neck strap is comfortably snug in that position. **(figure 3)**






figure 4

Open the nose loop wide enough to easily slip over your dog's muzzle. **(figure 4)** If the nose loop will not open wide enough, slide the keeper further TOWARD the end of the leash to allow more material in the loop.

Adjust the material of the nose loop to create a comfortable fit that stays in place. **(figure 5)** The nose loop can be loosened by pulling from the dog's left side. To tighten, pull from the dog's right side.




figure 5

Lastly, slide the keeper back toward your dog's jaw, leaving approximately 1 to 4 inches of slack, depending on the size of your dog. **(figure 6)** The idea is to leave enough room so that your dog can freely open his mouth to pant, but not so much slack that he's able to paw it off. [Shorter length for smaller dogs, longer length for bigger dogs.]

If your dog is able to paw the nose loop off his muzzle, adjust the keeper more closely to his jaw.

To take off the Wonder Walker, loosen the keeper and remove the nose loop first.




figure 6

Please Note:

NEVER hold tension on the dog's nose for more than 20 seconds. Be sure to allow enough slack for the dog to pant, drink, and take treats. Always allow slack in the leash after applying gentle pressure to redirect your dog's head.

Practice makes perfect...

If your dog is not accustomed to wearing a head halter, you may want to spend a little time getting him used to it. Practice on safe dogs in familiar surroundings. Plan several 5-minute sessions right before meal times. With your dog at your side, take 2-3 steps with him and have him sit. Should your dog show signs of stress or panic, loosen tension or release the leash altogether, rest a moment, and begin again.

There should not be constant tension on the leash - it's always a gentle pull and release. Jerking on the leash is never appropriate with the Wonder Walker. The tension tells the dog his pulling behavior is not what you want. The release of tension is the reward telling him "Yes!". Reward him -- with praise, petting, treats -- as he is successfully walking. Repeat this process at least 10 times.

Once he is successful at 2-3 steps, increase the number of steps. Once he learns loose leash walking at your side, you can give him more leash as long as he is not pulling.

Caution: DO NOT JERK on the leash. Gentle pressure is all you need to direct your dog's head. This product is intended for walking under handler's supervision only. Not recommended for tie-out, for jogging, or swimming. Please do not leave your dog unattended while wearing the Wonder Walker.